



**Vertical distance between holes**

	Inch	mm
A	1.5"	38.1
B	3"	76.2
C	2.5"	63.5
D	10"	254
E	5"	127

**Total Door Undersizing**

Single Square Edge Door – 15/32"  
 Single Bevel Edge Door – 1/2"  
 Pair of Doors, each leaf, Square Edge Door – 7/16"  
 Pair of Doors, each leaf, Bevel Edge Door – 15/32"

Reinforcement recommended for six hole pattern at top and bottom of each leaf of hinge.

**Hole Preparation (44 places)**

**Metal frame:**  
 Standard self drilling self tapping screws - No drilling required  
 Optional thread forming screws - #13 or 3/16" drill

**Wood frame:**  
 5/32" drill, 1.5" deep



112HD 95" Concealed Continuous Hinge Profile Template



**Note:** Dimensions in [ ] are millimeters

Template Number 829227-00(C)

Date: 11-10-11